

Fitment info for Polaris

PK1:

ACE* 900
GENERAL* 1000
2013+ RANGER* 900 & 1000
2013+ RZR* 900 & 1000
DOES NOT fit turbo models

PK2:

ATP* 330, 500
Hawkeye* 300, 400
Magnum* 325,330, 500
RANGER* 400
Model years 2016 and previous - RANGER* 500
Scrambler* 500,850, 1000
Sportsman* 300,400,450,500,550,570,850, 1000
Trail Blazer* 330
Trail Boss* 325, 330
Xplorer* 500

PK3:

ACE* 500, 570
2017 + RANGER* 500
RANGER* 570,700, 800
RZR* 570, 800
Sportsman* 600,700, 800

Fitment info for Can-Am

CK1 :

Maverick X3 2018-
Maverick X3 R 2017-
Maverick X3 RR 2020-
Maverick X3 Turbo 2018-
Maverick X3 Turbo R 2017-
Maverick X3 Turbo RR 2020-
Maverick Turbo 2019-
Maverick Turbo R 2019-
Maverick Turbo RR 2020-
Ryker 900 ACE 2019-

Fitment info for Can-Am

CK2 :

Commander 1000 2011-
Commander 1000R 2018-
Commander 800 2011-
Commander 800R 2012-
Outlander 500 2007-2015
Outlander 570 2016-
Outlander 650 2005-
Outlander 800 2006-
Outlander 800R 2009-2015
Outlander 850 2016-
Outlander 1000 2012-
Outlander 1000R 2016-
Renegade 500 2008-2015
Renegade 570 2016-
Renegade 800 2007-2008
Renegade 800R 2009-2015
Renegade 850 2016-
Renegade 1000 2012-
Renegade 1000R 2016-
Maverick 800 2019-
Maverick 800R Trail 2018
Maverick 1000 2013-
Maverick 1000R 2013-
Maverick Turbo 2014-2017
Defender HD8 2016-
Defender HD10 2016-
Traxter HD10 2017-
Traxter HD8 2016-

CK3:

Defender HD5 2017-
Outlander 400 2007-2015
Outlander 450 2015-
Traxter HD5 2017-